





OTHER PRODUCTS

BUFFER MOLECULAR BIOLOGY REAGENT & KITS NANOPARTICALS

LABORATORY EQUIPMENTS & OTHER CONSUMABLES LABORATORY CHEMICALS
PLASTICWARES & GLASSWARES



Phone +91-79757 90185 / 96009 17360

Email Website www.snlifesciences.com drmondal@snlifesciences.com

Address Bommasandra Industrial Area, No.57/90, 3rd Road, 4th Phase

Bengaluru - 560099











Extraction Kit SN RNA CATCHER Soil RNA

(Column Based)



SN SOIL RNA EXTRACTION KIT

(Column Based)

DESCRIPTION:

SN SOIL RNA Extraction Kit provides an accurate, easy to use & rapid method to isolate high quality RNA from various soil samples. The preparation is based on a silica-membrane technology for binding RNA in high-salt and elution in low-salt buffer. This kit provides a simple and efficient way to elute pure RNA in minimum steps.

CONTENTS OF KIT:

Sl.	Components	Volume		
<u>No</u>		5 Kxn	50 Kxn	100 Rxn
1	RS Buffer	1.5ml	15ml	30ml
2	LS Buffer	1.5ml	15ml	30ml
3	STB Buffer	2.5 ml	25ml	50ml
4	W1 Buffer	2ml	20ml	40ml
5	Elution Buffer	250μ	2.5ml	5ml
6	SN Spin Column & Collection	5 No.	50 No.	100 No.
	tube			

NOTE: Preparation for first use after receiving the kit (Add 100% Ethanol to Wash Buffer) (5Rxn: 500μ l, 50Rxn: 5ml, and 100Rxn: 10ml) mix well and store the buffer at room temperature.

- If Proteinase K shipped in lyophilized form, upon receiving resuspend with Nuclease free water (5Rxn:100μl,50Rxn:1ml, 100Rxn: 2ml) and store at -20°C.
- If Carrier RNA and DNase shipped in lyophilized form, upon receiving resuspend with Nuclease free water (5Rxn:50μl, 50Rxn:500μl, 100Rxn: 1ml) and store at -20°C.
- Proteinase K/Carrier RNA/DNase are store at -20°C either in liquid form or Lyophilized form.

REQUIRED MATERIALS NOT PROVIDED:

- ✓ 100% Ethanol
- ✓ Dry bath
- ✓ 1.5ml Centrifuge tubes
- ✓ micro centrifuge
- ✓ Vortex

STORAGE / SHIPPING:

- Shipped at: Ambient Temperature.
- Storage: All Buffers an be stored at Room temperature.

SPECIFICATIONS:

Principle	Spin Column		
Recommended Input Amount: 200mg Soil Sample			
Elution Volume : $50\mu I$ Recommended			
Purity: A260/280 - 1.8±0.1			
Compatible Down8treem Application: PCR, qPCR, Sequencing			
Expected Yield : ~ 20μg			

PROCEDURE:

- 1) Take 200mg of soil sample and add 300µl of RS buffer to a provided Bead tube and vortex thoroughly for 15mins.
- The mixture was centrifuge at 3,000rpm for 4 mins.
- 3) Transfer the supernatant to a fresh tube. Add 300μL of LS Buffer along with 20μL of Proteinase K, 10μl DNase and 10μl of carrier RNA. Vortex for 30secs.
- 4) Incubate at 56°C for 15mins.
- 5) Add 500μl of 100% ethanol and keep the tube for 2 mins at room temperature.
- 6) Transfer the complete precipitate to the SN Spin Column and leave at room temperature for 1min
- 7) Centrifuge at 15,000rpm for 1min and discard the flow-through in the collection tube.
- 8) Add 500µl of STB buffer to the SN Spin Column and centrifuge at 15,000rpm for 1min and discard the flow-through in the collection tube.
- 9) Add 500µl of W1 buffer to the SN Spin Column and centrifuge at 15,000 rpm for 1min and discard the flow-through in the collection tube.

Note: (W1 buffer concentration per reaction: W1 buffer -400μl: 100% ETOH -100μl)


- 10. Centrifuge the empty column at 15,000rpm for additional 1min.
- 11. Place the SN Spin Column in a new 1.5ml centrifuge tube and incubate for 10mins at 56°C. (with cap open).

NOTE: Elution should be pre-heated for 10mins before adding into the SN Spin Column

- 12. Add 50μl of pre-heated Elution Buffer to the membrane center of SN Spin Column and incubate for 4mins at 56°C (with cap close).
- 13. Centrifuge the tube at 15,000rpm for 1 min elute RNA(store at -20°C).

FLOW CHART:








Then centrifuge the tube for 4mins at 3,000rpm and then transfer the supernatant to fresh centrifuge tube.




• Add 300µl LS Buffer, 20µl of Proteinase K, 10µl of DNase and 10µl of carrier-RNA



- Mix well by vortexing for 30secs.
- Incubate at 56°C for 15mins.








- Centrifuge for 1min at 15,000rpm
- · Discard flow through
 - Add 500µl of STB buffer



 Centrifuge for 1min at 15,000rpm and Discard flow through



- Centrifuge for 1min at 15,000rpm
- Discard flow through
- Centrifuge for additional 1min at 15,000rpm



- Incubate at 56°C for 10mins (with cap open)
- Add 50µl of pre-heated Elution Buffer to the membrane center of SN Spin Column (with close cap)
- Incubate at 56°C for 4mins
- Centrifuge for 1min at 15,000rpm



 Elute Pure RNA (store at-20°C)

TROUBLE SHOOTING:

Problems	Possible reasons	Solutions
Low or none recovery of RNA fragment	Weigh 200mg of soil sample	If product is more, then separate it into multiple tubes.
	Elution of RNA fragment is not efficient	Make sure the pH of Elution Buffer or ddH_20 is between 7.5-8.0.
		Make sure that the elution solution has been completely absorbed by the column Membrane before centrifugation.
Poor Performance in the downstream	Salt residue remains in eluted RNA	Wash twice with W1 Buffer.
applications	Ethanol residue remains in eluted RNA	Do discard the flow- through after washing with W1 Buffer and centrifuge for an additional 1min.

IMPORTANT NOTES:

- a) Ensure that the ethanol has been added in the wash buffer.
- b) Buffer provided in this kit contains irritants. Wear gloves and lab coat when handling these buffers.
- c) Check stabilization buffer for salt precipitation before use. Re-dissolve the precipitated salt by warming it in 37°C.
- fresh TAE electrophoresis buffer is recommended on electrophoresis for experiments requiring high purity.
- e) Centrifugation steps are done by a micro centrifuge capable of the speed at 11,000 ~ 15,000 rpm